

SOURCE



General Installation Instructions

Cable is directional. Connector Head marked "**SOURCE**" must connect to Source. Connector Head marked "**DISPLAY**" must connect to Display. Cables installed improperly will not function.

If the Source or Display cannot provide adequate embedded 5V power external power is required. See other side.

DISPLAY



Installation with External Power

Cable is directional. For general installation instructions, see other side.

If Source or Display cannot provide adequate embedded 5V power, external power supply is required. Place included HDMI to USB cord inline at Source/Tx or Display/Rx. Diagram shows placement at Display/Rx. Connect USB to external 5V power supply (not included).



5V Power Supply
(Not Included)

